

PART #	DESCRIPTION
8812	ATTENUATOR
9931	BUTTON, ARROW SIDE
9932	BUTTON, ARROW UP/DOWN
9928	BUTTON, ENTER
9930	BUTTON, HELP
9929	BUTTON, MENU
9927	BUTTON, RUN
9958	CABLE ASSY. (HC 11)
4136	CAPILLARY ADAPTER, 1/4"
4138	CAPILLARY HOLDER, 1/4"
4148	CAPILLARY NUT
8919	CAPILLARY, 13 MIL L (BLUE/YELLOW)
4158	CHARCOAL (POUND)
8851	DIFFUSER
8630	FAN GUARD ASSEMBLY (W/Foam) "C-SERIES"
4299	FAN, COOLING, SPRITE 115V/50/60
4304	FEET, RUBBER (PK/4) ("C" Series Instrument Case)
8544	FEET, RUBBER (SHOCK MOUNTS) (Optical Benches)
8719	Filter, PMT (43C-TL, 450C-TL)
9934	FLOW TRANSDUCER ASSY. (HC11)
4510	FUSE 3 AMP S/B (PK/5)
5933	HEATER RESISTOR, 100 OHM (115 V) (Specify Instrument)
9886	INSTRUMENT, COVER
8746	KICKER ASSEMBLY
8666	LAMP, UV SOURCE (43/43A)
8850	LENS RELAY
13399	MANUAL, MODEL 43CTL
57P746	MIRROR ASSEMBLY, DUAL (43C-TL & 450C-TL)
4811	O-RING
4820	O-RING
4829	O-RING
4808	O-RING (Between Reaction Chamber)
4830	O-RING (PK/2)
4831	O-RING (PK/2)
4800	O-RING VITON (PK/10) (FOR CAPILLARIES)
8943	PCB A / D
9843	PCB C-LINK (Must Specify Program Version)
9904	PCB CONNECTOR INTERFACE
9839	PCB DIGITAL/ANALOG
11220	PCB DISPLAY
8884	PCB FLASH INTENSITY ASSY

PART #	DESCRIPTION
10996	PCB FLASHER SUPPLY
8951	PCB INPUT
9829	PCB MOTHER
8949	PCB POWER SUPPLY
9901	PCB POWER SUPPLY (PMT)
9279	PCB POWER SUPPLY PMT (HIGH VOLTAGE)
9837	PCB PROCESSOR (Must Specify Program Version)
9950	PCB PUSH BUTTON (B1)
9952	PCB PUSH BUTTON (B2)
8765	PCB TEMPERATURE CONTROLLER
8868	PHOTOMULTIPLIER TUBE (43A)
11519	PLUG 8 PIN (Rear Panel Terminal Strip)
100727-00	PMT Base Assembly, 43i
8165	POWER CORD, 115V
8709	PUMP (115V/50/60Hz) Specify Voltage and Model Number)
8550	PUMP KNF 115V/60HZ (PU603N056)
8551	PUMP KNF 230V/50HZ
8606	PUMP REPAIR KIT, KNF (FOR P/N 8550)
18061	RUBBER FEET (Insulator) (Feet for the Pumps)
8392	SOCKET ASSEMBLY, UV LAMP (43S)
12118	SWITCH POWER MODE SP3T
5382	THERMISTOR IM-1002-A5
9877	TRANSDUCER, PRESSURE ASSY.
5512	TUBING, TEFLON 1/4" (FOOT)