

PART #	DESCRIPTION
8542	ABSORPTION TUBE, CELL (49)
9976	BLOCK CLAMPING PHOTOCELL
8564	BLOCK INPUT/OUTPUT
9978	BLOCK MOUNTING PHOTOCELL
9931	BUTTON, ARROW SIDE
9932	BUTTON, ARROW UP/DOWN
9928	BUTTON, ENTER
9930	BUTTON, HELP
9929	BUTTON, MENU
9927	BUTTON, RUN
9958	CABLE ASSY. (HC 11)
6279	CABLE RS232 ASSY 6'
4124	CAPILLARY, 15 MIL S. (PURPLE)
8592	DETECTOR ASSEMBLY (49-11)
8630	FAN GUARD ASSEMBLY (W/Foam) "C-SERIES"
4299	FAN, COOLING, SPRITE 115V/50/60
4304	FEET, RUBBER (PK/4) ("C" Series Instrument Case)
8544	FEET, RUBBER (SHOCK MOUNTS) (Optical Benches)
9934	FLOW TRANSDUCER ASSY. (HC11)
4509	FUSE 2 AMP S/B (PK/5)
8549	GASKET SILICON (8546)
9886	INSTRUMENT, COVER
8557	INSULATOR LAMP BLOCK
8645	LAMP, OZONATOR (49)
8540	LAMP, PHOTOMETER (49)
9999	MANUAL, MODEL 49C
8546	MIRROR, RELAY (49)
8579	O-RING SILICON (PK/5)
10761	PCB ANALOG/DIGITAL (49C)
9843	PCB C-LINK (Must Specify Program Version)
9904	PCB CONNECTOR INTERFACE
9839	PCB DIGITAL/ANALOG
11220	PCB DISPLAY
9956	PCB I/O WITH CABLE ASSEMBLY
10763	PCB LAMP HEATER ASSY (MODEL 49C)
10758	PCB LAMP POWER SUPPLY (49C)
9833	PCB MOTHER (49C)
10760	PCB OZONATOR
9847	PCB POWER SUPPLY (49C)
9837	PCB PROCESSOR (Must Specify Program Version)
9950	PCB PUSH BUTTON (B1)

PART #	DESCRIPTION
9952	PCB PUSH BUTTON (B2)
8541	PHOTO-DIODE FOR DETECTOR (P/N 8592)
8556	PLATE O-RING
11519	PLUG 8 PIN (Rear Panel Terminal Strip)
8165	POWER CORD, 115V
8709	PUMP (115V/50/60Hz) Specify Voltage and Model Number)
8550	PUMP KNF 115V/60HZ (PU603N056)
8551	PUMP KNF 230V/50HZ
8606	PUMP REPAIR KIT, KNF (FOR P/N 8550)
18061	RUBBER FEET (Insulator) (Feet for the Pumps)
14697	SCRUBBER ASSEMBLY (49C)
13405	SOFTWARE, C-LINK (49C)
12118	SWITCH POWER MODE SP3T
8314	THERMISTOR ASSEMBLY (49)
9877	TRANSDUCER, PRESSURE ASSY.
5496	TUBING, SILASTIC (FOOT)
5512	TUBING, TEFLON 1/4" (FOOT)
8573	VALVE SOLENOID 3-WAY (SPECIFY INSTRUMENT)
8545	WINDOW QUARTZ