

Thermo Scientific Orion Diffusion Tubing Assembly Kit

Instructions for 1800 Series and 2100 Series Analyzers

The three O-rings should be used as face seals when removing the bottle adaptor to replace the diffusion tubing. Refer to the **Reagent and Diffusion** section of the appropriate 1800 series or 2100 series analyzer user guide for the installation instructions.

Instructions for 1517 and 1518 Analyzers

Tubing for the Thermo Scientific Orion 1517 analyzer has been improved and is no longer offered as one 10 foot length. The current catalog number for re-ordering is Cat. No. 150061, which consists of one 3 foot length of tubing.

Tubing for the Thermo Scientific Orion 1518 analyzer has been improved and is no longer offered as Cat. No. 150060, which consisted of one 4 foot length. The current catalog number for re-ordering is Cat. No. 181060, which consists of one 2 foot length of tubing.

Bulk tubing for the 1517 and 1518 analyzers may be purchased as Cat. No. 180063, which includes one 100 foot length of tubing.

***Note:** The two smaller O-rings previously enclosed to prevent leaks at tubing connectors are no longer included. An improved nipple on the tubing connector has eliminated the need for these O-rings.*

If you experience tubing falling off of the nipples or the reagent bottles overflowing, you may require a tubing connector with the new style nipples. To order, please contact our Customer Service department and order the newest tubing connector, Cat. No. 702310-A03.

Assistance

After troubleshooting all components of your measurement system, contact our Technical Support department. Within the United States call 1.800.225.1480 and outside the United States call 978.232.6000 or fax 978.232.6031. In Europe, the Middle East and Africa, contact your local authorized dealer. For the most current contact information, visit www.thermo.com/contactwater.

©2009 Thermo Fisher Scientific Inc. All rights reserved. All trademarks are the property of Thermo Fisher Scientific Inc. and its subsidiaries.



Process Water Instruments

North America
166 Cummings Center
Beverly, MA 01915 USA
Toll Free: 1-800-225-1480
Tel: 1-978-232-6000
Dom. Fax: 1-978-232-6015
Int'l Fax: 978-232-6031

Europe
P.O. Box 254, 3860 AG Nijkerk
Wallerstraat 125K, 3862 CN
Nijkerk, Netherlands
Tel: (31) 033-2463887
Fax: (31) 033-2460832

Asia Pacific
Blk 55, Ayer Rajah Crescent
#04-16/24, Singapore 139949
Tel: 65-6778-6876
Fax: 65-6773-0836

www.thermo.com/processwater