

PRODUCT BULLETIN

INTERNAL MODEM KIT PARTISOL[®]-PLUS AIR SAMPLER

The internal modem kit option for the Partisol-Plus Air Sampler permits remote communication via a phone line. The kit features a heavy-duty modem with a rated temperature range from -40 to 85 °C. This product is available as a user-installed option, and includes the complete instructions and parts required for simple installation. The modem has a rating of 14.4 kbs, and is operated at 9600 baud to ensure error-free data transfer.

The internal modem kit is available as Thermo part number 59-005707.



Removing pump compartment panel for installation of modem kit.



Front view of Partisol-Plus Sampler with modem kit installed.



Installing modem located on replacement panel.



Detail of serial connection from Partisol-Plus Sampler to modem and RJ-11 jack to outside telephone line.



Air Quality Instruments
rp Products
www.thermo.com/air

26 Tech Valley Drive (518)452-0065
East Greenbush, NY 12061 (518)452-0067 fax

ISO9001:2000
Certified